



0205800 / TBXS – 0205801 / TBXSM - 0205812 / TBXSN
0205814 / TBXSB - 0205810-0205815-0205813 / TBXSSC
WASTE FOR SHOWER TRAY Ø90 Turb@flow[®] XS

FUNCTION :

- Super flat trapped waste for shower trays with ø90 mm hole
- Adapted to ultra-flat shower trays

DESCRIPTION :

- Body : co-injected with built-in seals.
- Removable Magnetech flap, with 10 mm height water seal.
- Anti-vacuum air intake function
- Clamp, **cannot be cut**, long and short

TECHNICAL FEATURES :

- Materials :
 - Co-injected body : polypropylene + ABS + elastomere
 - Co-injected flap : polypropylene and elastomere
 - Clamp : POM
- Dimensions :
 - Compactness : 52 / 66 mm
 - Connection to the waste pipe : compression G1”1/2 – or to be glued : ø40 mm.
 - **Tightening thickness : The MAGNETECH system doesn't work with a tightening thickness less than 6 mm**
- Flow rate : 33 l/min under a 15 mm water load



0205800 / TBXS



0205812 / TBXSN



0205814 / TBXSB

CODE NUMBER	COVER	THREADED CLAMP	TIGHTENING THICKNESS
0205800 / TBXS	ABS CHROME	LONG AND SHORT	6-17 short clamp / 15-25 long clamp
0205801 / TBXSM	METAL CHROME	LONG AND SHORT	6-17 short clamp / 15-25 long clamp
0205814 / TBXSB	BRIGHT WHITE ABS	LONG AND SHORT	6-17 short clamp / 15-25 long clamp
0205812 / TBXSN	MATT BLACK ABS	LONG AND SHORT	6-17 short clamp / 15-25 long clamp
0205813 / TBXSSC	WITHOUT COVER	LONG AND SHORT	6-17 short clamp / 15-25 long clamp
0205810 / TBXSSC	WITHOUT COVER	LONG ONLY	15-25 long clamp
0205815 / TBXSSC	WITHOUT COVER	SHORT ONLY	6-17 short clamp

SUPPLIED ACCESSOIRES :

- Thickness template to choose short or long threaded clamp (except 0250810 and 0205815)
- Multifunctions spanner :
 - Clamping tool with torque limiter.
 - Cover support
 - Hair catcher (versions with cover)

NF CERTIFIED :
- NF 077 DT-16





0205800 / TBXS – 0205801 / TBXSM - 0205812 / TBXSN
0205814 / TBXSB - 0205810-0205815-0205813 / TBXSSC
WASTE FOR SHOWER TRAY Ø90 Turb@flow[®]XS

INSTALLATION :

- Choosing between short or long threaded plate depending on the shower tray thickness ;
- Connection of the outlet to the waste pipe : compression G1”1/2 or to be glued : $\varnothing 40$ mm ;
- Assembly of the shower drain on the tray (threaded clamp) ;
- Installation of the Magnetech flap inside the shower drain ;
- Push the flap all the way in to make it airtight
- Put the multifunctions spanner and the cover on the top of the shower drain.(except versions without cover)

MAINTENANCE :

- The use of aggressive cleansers is prohibited on the chrome plated parts.
- Do not use white vinegar.
- Removable hair catcher.
- Removable Magnetech flap for easy access and cleaning.

